

For Information Updates refer to: <u>www.brultech.com/ecm1220h.html</u>

Introduction / How It Works

The ECM-1220.H Monitor / Logger is a two channel power meter. It tracks and records the true (real) power consumed by an electrical load. The term "load" represents an appliance, a machine, a lighting circuit, or any electrical device which consumes electrical power. In order to derive true power a power meter requires "real time" access of two parameters:

- 1. The voltage (Volt) supplied to the load.
- 2. The current (Amperes) flowing through the load.

In order to access these parameters from a powered load, the ECM-1220.H uses the most non-intrusive and safe method of doing this:

- The ECM-1220.H reads the line voltage (120V household voltage) via the supplied AC wall transformer (usually termed AC adaptor). The low voltage secondary AC signal from the wall transformer is proportional to the line voltage. With this technique, there is no need to connect to dangerous voltage levels. When a transformer is used in this way, it is termed **Potential Transformer** (PT).
- In order to access the load's current without splicing into a current carrying conductor, the ECM-1220.H uses two Current Transformers (CT). The CTs simply clamp around each line conductor supplying the load.

Since the monitor obtains the required parameters indirectly, it is important for the ECM-1220 to know the value of the wall transformer's (PT's) ratio of primary to secondary voltage (Factory Set). The ECM-1220 also requires the CT's ratio for an accurate representation of the current. These values are labelled on the PT and CT.

It is very important to verify that your ECM-1220 is set to these values (preset at factory) Once this is done, the ECM-1220 will always remember these values until they are manually altered. In other words, this only needs to be setup once, unless the CT is substituted with another type for higher current applications.



Once the ECM-1220 is setup and monitoring a load, the energy consumption may be monitored and recorded in several ways:

- The non-volatile incrementing counter which display the kWh value, much like a residential power meter. This counter keeps incrementing (with power usage) until the user decides to reset it.
- 2. The ECM-1220 also has internal memory for data logging. The "data logging" records and saves power consumption data at a regular interval. This interval setting is selected by the user. Although the data is saved at periodic intervals, this data represents and average of continuous sampling (several hundred samples per second). *This feature is available with the download option only.*
- 3. The other method of monitoring is to have the ECM-1220 connected to a computer via USB cable or wirelessly via *optional* ZIGBEE. With this method, data can be collected at a resolution as low as once per second.



<u>Safety</u>

WARNING



- Power the ECM-1220.*H* with the supplied UL/CSA approved wall transformer only.
- For indoor use only.
- If installation is required in a damp location. Power the ECM-1220 via a GFI/GFCI protected outlet.
- Installations requiring access to service panels, sub panels, junction box or any others situations where live wires are exposed must be performed by a <u>qualified person or electrician</u>. This individual must be <u>familiar with the proper safety practices and equipped with the required PPE (Personal Protective Equipment)</u>.
- Any installations requiring access to service panels, sub panels, junction box or any others situations where live wires are exposed are to comply with local safety codes and regulations.
- Never connect the provided current clip to a bare or un-insulated conductor.
- Prior to installation, always inspect the condition of the current transformer cable. Any damage to the cables' outside insulations must be repaired or the CT (current transformer) replaced.

© Brultech Research Inc



Installation

The current transformers (CTs) will have to be installed inside the service panel to be monitored. <u>This</u> part of the installation must only be performed by an electrician or authorized, knowledgeable person. It is also important to obey all local Electrical Codes when installing the CTs. Once both CTs have been installed with their signal cables exiting the panel, the remainder of the installation consists of safe, low voltage, signals which are isolated from the power line.

The SPLIT-200 CTs (blue clamps) included in your kit need to be snapped around the insulated line feeding the service panel. It should be installed on a "straight" section of the line wire and should never be forced on.











The ECM-1220.H-WR has been designed to be mounted flush to the wall. One of two methods should be used for mounting the ECM-1220.H-WR:

(1)





(2)



 $\ensuremath{\mathbb{C}}$ Brultech Research Inc

www.brultech.com



If the ECM-1220.H is to be mounted at a distance from the panel, the SPLIT-200 wiring may be extended using Category 5 cable or Quad (telephone type) cable. The wall transformer may be located near the monitor if desired, thereby eliminating the need to run the 12Vac signal from the panel to the monitor.

[©] Brultech Research Inc



ECM-1220.H-WR



Verifying / Changing Settings

Read all safety precautions relating to the type of monitoring installation used.

Verify the PT setting of the monitor matches that of the supplied "Wall Transformer". This is factory set to the PT that is shipped with the unit. Generally, there is no need to change this value unless a different PT is used for a specific application.

Verify the CT setting with that of the CT you will be using. A separate setting is required for each channel based on the CT type being used. The default value from the factory is TYPE: 100 and RANGE: 5. This makes it compatible with the Split-60 (SCT-60-B) CT.





Flowchart showing the various ECM-1220 settings and the key sequence required





Viewing Information

The first option on the "Main Menu" is "Display". Once installed and setup, your monitor will be in this mode for viewing the desired values.



After selecting the "Display" screen, you need to select which channel you would like to view. The "Total" option displays the sum of channel one and two. This option is handy when monitoring a 240V load using two CTs. The "Total" will be the sum of the power from each leg. Use the UP or DOWN key to select the desired channel, then SEL.

C Brultech Research Inc

The "Display" screen shows various parameters. The top line of the LCD display is independent of the bottom line. This provides the user with a multitude of display options. To change the top line, use the UP key. The DOWN key will change the bottom LDC display line.

In the display mode, SEL has effect on only one parameter, "PEAK". The "Peak" display is used to record the highest Watt value monitored. To reset (erase) the "Peak" value, press the SEL button for approximately 6 seconds, while on the "Peak" display.

Resetting the Unit

Option "3. Reset" from the main menu is used to reset all cumulative values to zero.

This option has two prompt pages, to help prevent accidental erasure of data.

Firmware

Option "4. Firmware" displays the firmware version of your monitor.

What is firmware?

The firmware is the program that runs the Energy Monitor. This is equivalent to a computer program. The computer program performs certain tasks and has specific features. On occasion, the software company may release a new version of their software with more options or improvements. The same is true for the ECM-1220's firmware. It is called firmware because it stays resident in your Energy Monitor and the unit will always "boot-up" with this program.

As Brultech Research releases newer versions of the firmware with improvement, the end user may upgrade the firmware by re-programming the ECM-1220's internal memory.

The firmware and required drivers and software are downloadable from www.brultech.com/ecm1220/firmware. The optional USB data cable may be ordered from the company you purchased your monitor from.

C Brultech Research Inc



Data Logger

The data logger section is only viewed by downloading the collected data using the optional software.

How the Logger Collects/Records Data:

The data logger section of your monitor continuously tracks the amount of energy used, then at the user selected storage interval, stores the average energy for that period.

For example:

Suppose the monitor's storage interval is set to store data every 10 minutes and during 5 minutes of that interval a 500 watt loads is operated, then OFF for 5 minutes, the stored data would be 250 watt. This is the average power used during that interval. Once downloaded the software will calculate and display the accumulated kilowatt-hour during that interval. For the same scenario as above, if the storage interval was set to 1 minute storage interval, after 10 minutes, 10 data records would have been stored; 5 records of 500 watt and 5 records of 0 watt.

From this example, it is obvious that a lower storage interval is preferred. The trade-off is the amount of time you can monitor before the data logger memory becomes full.

The data logger collects and stores data at its user programmed storage interval until the memory is full. Once the memory is full, it WILL NOT overwrite the data. At that point the data is no longer recorded. This has NO EFFECT on the Energy Consumption Monitor's operation, as it will continue to operate normally.

When the Energy Monitor is RESET, the data logger memory is cleared then starts logging at the beginning. This also resets the Energy Monitor's cumulative data such as KWh, Cost and Elapsed Time.

Downloading Data Logger Records:

The download software is optional and comes with various drivers and USB data cable.

Before data can be downloaded for the first time, two "drivers" will need to be installed on the computer. The software CD has the drivers and installation instructions.

Once the drivers are installed the Energy Monitor is then connected to the USB port of your computer with the supplied data cable. (When connected for the first time, Windows will discover the new hardware). The download procedure is straightforward, using the software.



Real Time Data

The optional software comes with the ability of viewing energy usage in "real time" (as it happens). When enabled with the software, data is transferred to the connected computer every second. The data transferred is:

CH1 Power (watt) CH2 Power (Watt) Line Voltage (volt)

This information is displayed in a scrolling box. The data displayed can be transferred from the box to another program by highlighting the records, saving it to the clipboard, then pasting it into your application. When pasting to a spreadsheet, the "tab delimited" option should be used.



Display:

Size:	5 ½" X 4" X 1 ½"
Power:	Digitally sampled true power . 1 Watt to 65,000 Watt (1 Watt resolution)
Power/KWH Accura	cy: ± 1% plus CT accuracy Typically ± 2% with most current sensors
Energy:	.001 kWh to 16,777.216 kWh (.001 kWh resolution)
Voltage:	85V to 480V depending on the Potential Transformer used. Standard Package Comes With PT:
	Line Voltage: 85V to 130V <u>Secondary:</u> 12VAC 300mA 3.5mm mono phone plug Use <u>ONLY</u> supplied "Wall Transformer"

2 Lines X 16 Characters Alpha Numeric Blue background with white backlight

CT Inputs (balanced):

333mV RMS Full Scale, 353mV RMS Max Input Impedance: 20Kohm Stereo 3.5mm Plug: Ring(-V), Tip(+V) Sleeve(N.C.)

CT Inputs (unbalanced):

3.0 V RMS Max Input Impedance: 107 Ohm Mono 3.5mm Plug: Tip(+) Sleeve(-)

Input Current: Dependant on Current Transformer

Wall Plug Adaptor (WPA-3) Rating:

120 VAC 15 Amps

Elapsed Monitoring Time:

MAX: 255 days, 23 hrs, 59 min, 59 seconds (1 second resolution)

Rate (cost for electricity):

0.1 /kWh to 99.9 ¢/kWh (in 0.1 ¢/kWh resolution)

Displayed Cost of Energy:

0.1¢ to \$ 12000.00

Projection Period:

1 day to 255 days (typically set to 7days, 30 days, 60 days or 90 days)

Data Logger Storage Interval:

From 1 minute to 255 minutes (1 minute increments) (Stored data is the average of thousands of samples over that period)

Data Logger memory:

EEPROM Technology (non-volatile)

Standard Unit 13,080 records Optionally expandable to 52,401 records (in 13,107 increments)

Firmware: Flash, user reprogrammable